



Perten AM5200-A Calibration Update Instructions

If your Perten AM5200-A is showing the “**Service Date Has Been Reached**” message, this is a friendly reminder that your machine is due for the latest calibration update. The USDA updates these calibrations May 1st and August 1st of each year to ensure accuracy of moisture meters throughout the commercial grain trade. Here are a few simple options to clear the message and/or update your machine.

Option 1: Login as admin with code: 142857 and touch [**Remind me Later**]. This will clear the message for 7 days. Login instructions can be found below on page 2, step 4.

Option 2: Call 877-856-0060 or order a USB stick with the update file & printed instructions from www.scottagsolutions.com/support . Importing this update will update your calibrations and clear the message until the next update is due. See page 2 for Import instructions.

Option 3: Download the calibration update for free from our website and save it the file to your own USB stick and import into your machine. This will also clear the reminder message until the next update is due. See below for free download and import instructions. **Please Note:** these instructions are for the **AM5200-A** only, and **not** for the AM5200-FARM.

Option 4: If your machine has not been serviced in a while, it might be a good idea to call and discuss our **service** options. We can take care of any updates, repairs, preventative maintenance, and calibration for you.

Downloading the Calibration Update

1. Insert a blank USB stick into your computer. USB sticks with less GB storage capacity tend to work better than ones with more GB.
2. Go to <https://scottagsolutions.com/support/> and click on [**Calibration Updates**].
3. Select Perten AM5200-A and click [**Download FREE Update**]
4. Once the download is complete, double click on the downloaded file to open it.
5. Drag & drop or copy & paste the folder named “**perten**” to your USB stick. Your USB stick should now have a folder named “perten” inside it. If not, give us a call.
6. If successful, remove USB stick from your computer and see page 2 for import instructions.



Importing the Calibration Update into your Perten AM5200-A

1. Touch: **[Menu]** > **[Down Arrow]** > **[System Info]**
If the UI Software version is 20160701.02 press **[Exit]** and proceed to the next step. If it is **not** 20160701.02, **STOP** here and give us a call.
2. Unplug all USB and ethernet cables from the back of your AM5200-A.
3. Insert the USB stick with the latest calibration update into either of the USB ports on your AM5200-A.
4. Touch: **[Menu]** > **[General Settings]** > **[Login]** > **[Default]** > **[1]** **[4]** **[2]** **[8]** **[5]** **[7]** > **[the green enter button]** > **[Close]**.
5. Touch: **[Menu]** > **[General Settings]** > **[Maintenance]** > **[System Recovery]** > **[Set a Restore Point]** - After it is done creating a restore point, the unit will restart.
6. Touch: **[Close]** > **[Menu]** > **[General Settings]** > **[Login]** > **[Default]** > **[1]** **[4]** **[2]** **[8]** **[5]** **[7]** > **[the green enter button]** > **[Close]**
7. Touch: **[Menu]** > **[Down Arrow]** > **[Import/Export]** > **[Import]**
After import is successful, remove the USB Stick, touch **[OK]** and Restart the unit.
8. Verify the **Calibration Version** is updated to the latest version by touching: **[Menu]** > **[Down Arrow]** > **[System Info]** > **[Down Arrow]**.
9. If successful, touch **[Exit]**. Reinsert USB cables and/or ethernet cables.

If you have any questions, please don't hesitate to call us at 877-856-0060. We appreciate your business and look forward to serving you.